

Hy-Security Gate Operators

**222 SS, 222 E, 222 EX, 222 X1 SLIDE GATE
OPERATOR HANDBOOK**



Manufacturers and Designers of Hydraulic Systems

READ THIS FIRST!

Important Information

Automatic gate operators provide convenience and security to users. However, because these machines can produce high levels of force it is important that all gate operator system designers, installers and end users be aware of the potential hazards associated with improperly designed, installed or maintained systems. Keep in mind that the gate operator is only one component of the total gate operating system. It is the joint responsibility of the specifier, designer, purchaser, installer and end user to verify that the total system is safe for its intended use. All parties should be aware that entrapment in a moving vehicle gate can cause serious injury or death.

Common Industry Symbols



Attention
–Take Note–



–Danger–
Keep Away




Entrapment
Zone



Possible
Pinch Point


Cautionary Notes also see illustration on next page:

- Hy-Security gate operators are designed for vehicular traffic; *not pedestrians*. Direct all pedestrian traffic to a separate walk-through gate, and clearly display the warning signs on both sides of the vehicle gate.
- Verify that the gate operator is marked as appropriate for the type and usage class of the gate. External sensors must be installed to protect against accidental entrapment in both the opening *and* closing directions of gate travel.
- This type of gate operator must not be installed on the public, or non-secured side of the gate. To minimize the risk of entrapment, assure that the installation includes sufficient clearance between the gate and adjacent structures.
- Children must never be allowed to play on or around the gate.
- All access controls must be mounted at least six feet away from the gate and have a security feature to prevent unauthorized use.
- Install entrapment protection devices and sensors devices appropriate for the type of gate and usage class application: cover exposed rollers, screen across the face of the gate, install electric edge sensors, photoelectric sensors, guard posts, and moving gate alarms. Test all of your entrapment sensors to insure that they are working in the proper manner.
- Install physical stops for the gate panel, in each direction. This will assure that the gate does not accidentally travel farther than intended.
- Always make certain the operator is properly electrically grounded.
- Construct or screen automatic sliding gates, from the bottom of the gate to a minimum height of four feet, so that a sphere 2 1/4" in diameter cannot pass through. The 2 1/4" restriction also applies to the portion of the adjacent fence that the gate covers when open.
- When constructing/installing sliding gates, always minimize the gap between gate and fence. The gate must move freely in both directions. Never over-tighten a clutch or relief valve to compensate for a stiff gate.





Entrapment Protection Device Schematic for Sliding Gates





NOTE: All wheels must be covered. (Wheels and covers not shown for clarity).

*This schematic view is not meant to recommend the only way to set up your configuration, but to point out the various elements of a proper automatic vehicular gate installation. The gate operator itself is only one component in the total system. **Always install a separate pedestrian gate.***

Power transmission: Hydraulic motors to drive rail

Polyurethane drive rail wheel tread eliminates the high wear metal-to-metal contact of conventional chain-drive systems.




TITLE	eóÇê~ì ääÀ=pääÇÉ= d~íË=I eËê~íçë		
-------	-------------------------------------	--	--

DRAWN KERI	DATE 6/1/00	THIRD ANGLE PROJECTION 	REV --
CHECKED	DATE	PART NUMBER	
SHOP	MM/YY/DD	N/A	
APPROVED ENGRNG	DATE MM/YY/DD	DRAWING NUMBER: S12	SHT OF 1 1

Exploded Parts Breakout


Parts, Part Numbers and Kits



Slide Gate Operator Exploded Parts Breakout

Exploded Parts Breakout


Related Pump Packs



EX, CX, X1, XS Models

Exploded Parts Breakout

Related Pump Packs




LS, SS, CF, E, CE Models

ITEM #		QTY
2-1	ECOWI 144 0FLX	1 EA.
2-2	ESWDI 050 3P	1 EA.
2-3	ESWPB 030	1 EA.
2-5	ESWLS 224 LONG	1 EA.
2-6	ESWLS 224 SHRT	1 EA.
3-1	HSFFI 853 0610	4 EA.
3-2*	HMOMO K10 ERS	2 EA.
3-3	HSFHO 222K	3 EA.
3-4	HMAMA 222 BVK	1 EA.
4-1	M SLDU 012 SS	2 EA.
4-2	MSLDU 042 T	1 EA.
4-3	MSLDU 042 B	1 EA.
4-4	MSLDW 006 HY	2 EA.
4-5	MSLDW 008 HY	2 EA.
4-7	MSLLR 012 B	1 EA.

FOR 222 XI OPERATOR
SAME AS ABOVE WITH
THE FOLLOWING EXCEPTIONS:

ITEM #		QTY
* 3-2	HMOMO K24 ERS	2 EA.




TITLE
COMPONENTS ALL A.C. SLIDE OPERATORS, EXCEPT 111 LS

DRAWN	DATE	THIRD ANGLE PROJECTION		REV
D.B.	6/26/00			A
CHECKED	DATE	ERN NUMBER	DATE	
-	-	-	-	
APPROVED	DATE	DRAWING NUMBER:		SHT OF
-	-	SS34A		1 1

NOTES:

DRIVE RAIL HEIGHT IS MARKED ON THE SIDE OF EACH CHASSIS.

COVERS MUST BE USED FOR PROTECTION ON ALL EXPOSED WHEELS AND/OR HARDWARE. COVERS ARE SHOWN HERE AS DOTTED LINES.



ELEVATION

SECTION

NOTES:

CONSULT FENCE CONTRACTOR FOR RECOMMENDED CANTILEVER POST SPACING. 50% OF GATE OPENING GENERALLY PROVIDES SMOOTH OPERATION.


RIGHT HAND CANTILEVER GATE IS SHOWN IN THE FULLY CLOSED POSITION. OPERATOR COVER OMITTED FROM DETAIL. (DO NOT SCALE).

IT MAY BE NECESSARY TO SHIM DRIVE RAIL IF GATE PANEL IS "BOWED". RAIL MUST BE INSTALLED IN A STRAIGHT LINE.



TITLE	DRAWN			DATE	THIRD ANGLE PROJECTION	REV
SLIDE GATE OPERATOR (TYP) R.H. CANTILEVER GATE PANEL	KERI			6/12/00		---
	CHECKED			DATE		PART NUMBER
	SHOP			MM/YY/DD	N/A	
	APPROVED			DATE	DRAWING NUMBER:	SHT OF
	ENGRNG			MM/YY/DD	S13A	1 1


FENCE LINE




NOTE: CANTILEVER WHEELS MUST BE COVERED TO HELP PREVENT INJURIES. COVERS SHOWN HERE IN DOTTED LINES.

NOTE:
 MINIMUM CONCRETE SLAB DIMENSIONS RECOMMENDED ARE:
 30" WIDE, 20" FROM FRONT TO BACK AND 16" DEEP.
 CHECK LOCAL FROST CONDITIONS AND SOIL CHARACTERISTICS
 FOR EXACT REQUIREMENTS IN YOUR AREA.

OPERATOR IS INSTALLED ON A CONCRETE PAD AND CONNECTED
 TO THE RIGHT HAND CANTILEVER GATE PANEL. 4" POSTS ARE
 SHOWN FOR GATE SUPPORT AND FENCE TERMINATION.



DIMENSIONS OF OPERATOR AND BASE
 (FENCE/GATE SIDE)



NOTE:
 CONTACT A FENCE CONTRACTOR FOR EXACT SPACING ON CANTILEVER POSTS.
 50% OF OPENING WIDTH GENERALLY PROVIDES A SMOOTH OPERATION.




TITLE
**SLIDE GATE OPERATOR (TYP) R.H.
 CANTILEVER GATE PANEL**

DRAWN KERI	DATE 6/12/00	THIRD ANGLE PROJECTION 	REV --
CHECKED SHOP	DATE MM/YY/DD	PART NUMBER N/A	
APPROVED ENGRNG	DATE MM/YY/DD	DRAWING NUMBER: S13B	SHT 1 OF 1

VERTICAL GATE MEMBER

"U" BOLTS

LIMIT SWITCH RAMP



KEYWAYS FOR SPLICE PINS


LIMIT SWITCH RAMP

LIMIT SWITCH WHEEL

OPERATOR


LIMIT SWITCH ARM

LIMIT SWITCH BODY



SECTION THROUGH DRIVE RAIL AND LIMIT SWITCH SHOWING RELATIONSHIP OF SWITCH, LIMIT RAMP AND DRIVE RAIL.

SIDE VIEW OF LIMIT RAMP AND LIMIT SWITCH IN OPERATION. TAPERED ENDS, ALWAYS POINT TOWARD THE OPERATOR DRIVE WHEELS.



NOTE: ALUMINUM RAIL SHOWN, STEEL RAIL SIMILAR.



TITLE

DRIVE RAIL SLIDE GATE OPERATION

DRAWN

KERI

DATE

6/12/00

THIRD ANGLE PROJECTION



REV

CHECKED

SHOP

DATE

MM/YY/DD

PART NUMBER

N/A

APPROVED

ENGRNG

DATE

MM/YY/DD

DRAWING NUMBER:

S22

SHT

OF

1

1



Hy-Security Gate Operators

Phone: 1-800-321-9947 • Fax: (206) 286-0614 • Web: www.hy-security.com • 1200 W Nickerson St • Seattle, WA, 98119

Installation Instructions for Hydraulic Sliding Gate Operators (Except DC versions)

1. See drawings S13A & S13B for concrete slab size, operator footprint, and spacing dimensions. With the aid of the template enclosed inside the operator, locate the operator with clearance of 1-3/4" to the gate panel.
2. Mount operator to pad with a minimum of four concrete anchor bolts of 1/2" diameter.
3. Remove the plastic shipping plug on the pump manifold and replace it with the vented cap supplied. You will find it in a box with the plastic limit ramps.

4. Entrapment Protection - minimum safeguards:

- A. Since automatic gates are not intended for pedestrian use, always install a separate pedestrian walkway and access gate. Install signs which direct persons to use the pedestrian gate, and to not enter through the vehicle gate.
- B. Be certain that all open gate rollers are completely guarded by covers.
- C. Be certain that the gate has been constructed such that the opportunity for persons to reach through any opening have been minimized. A sphere 2-1/4" must not pass through any part of the gate, or the fence adjacent to the gate when fully open. It may be necessary to install screening to prevent reach through injury.
- D. Placement of physical stops for maximum open and maximum close is essential to prevent any over travel that might allow the gate to fall. The limit ramps are not to be used as gate stops.
- E. Be certain that all access controls are located at least a six foot distance from the gate, to reduce the possibility of any attempt to reach through in order to operate the gate.
- F. Be certain to mount at least two of the enclosed 8-1/2" x 11" warning placards on each side of the gate to warn users of the hazards of a power operated gate.
- G. **Button Station Operation:** Be certain to mount a warning placard near each button station that warns that the area must be clear before operating the gate. If there are no entrapment protection sensors to guard the open and close operation of the gate, the push button station must be wired for constant hold operation only. This is achieved by cutting jumper wires in the control circuit, see drawing E63T2 or E55T2 for the 111 LS model.
- H. **Automatic Operation:** Entrapment protection sensors must be installed to guard both the opening and closing of the gate. Install two photo electric eyes, or attach a minimum of two edge sensors to create a reversing function for each direction of gate travel. All sensors guarding the closing direction connect to terminals #1 and #6 in the control box. All sensors guarding the opening direction connect to terminals #9 and #6. See drawing #E41 for mounting and connection details of the edge sensors.

Caution: vehicle detectors are not entrapment protection sensors.

5. Connect appropriate power wiring. Be certain to oversize supply conductors to allow for voltage drop, especially for single phase machines. Follow the wire size schedules (drawing# E16a,b). Machines that are to operate on voltages above 120 do not need a neutral wire. Route conduit to the front left corner of the control box. Wirenut the supply power wires to the loose wires at the back of the on/off switch. Be certain to connect a ground wire.

6. Verify that the primary tap of the control transformer is connected to match the supplied voltage. It is especially important to distinguish between 208 and 230 volt supplies. The various voltage taps are identified by a label on the transformer or in the electrical drawings.

7. Test the basic functions of the operator first, before connecting any external control wiring. If your operator is equipped with vehicle detectors, be certain that they are connected to a loop or un-plugged so that they do not cause interference with the function of the machine. If the motor turns, but nothing moves, reverse two poles of a three phase power source. Also be certain that the hose quick connectors are firmly engaged. If the open and close functions are reversed, refer to step 9.

8. All operators are manufactured to be right hand. If reversing the hand is necessary, first swap locations of the two limit switches (do not change the wires, just move the limit switches, the cords are long enough). On 222 models, the handing can be changed by simply unplugging and reversing the limit wiring on the left side of the control enclosure. A label is affixed on the control panel which describes this procedure in more detail. It is also necessary to reverse the two hydraulic hoses going to the pump. On the 111 LS operators, a wrench will be required to remove and reattach the hoses. All 222 models are provided with hydraulic quick connectors which require no tools to reverse handing. Run the operator to verify correct functioning. If the hydraulic hoses were incorrectly reversed, the gate will move in the opposite direction than commanded. If the limit switch cords were incorrectly reversed, the operator would not stop when the gate reached its full travel. Never reverse wiring to the push button station.

9. After testing the basic functions, follow our electrical connection diagrams to add any accessories or external control wiring. Test the operator functions again.

10. Install drive rail on gate panel at the specified height. The drive rail must be close to the center of the cutout in the operator housing as it passes between the drive wheels. Check to see that the arms supporting the wheels are at similar angles from horizontal. Be sure that the drive rail maintains a consistent height in relation to the operator wheels, throughout the travel of the gate. (This may not be level or parallel with the gate frame because the gate panel and the fence may not be level.) The maximum up and down variance of the drive rail, as it passes between the wheels, is one inch for the entire length of the gate travel. The point at which the rail should pass between the wheels is marked on the exterior of the operator housing.

11. Actuate the toggle clamp to grip the wheels onto the drive rail. Gauge the tension on the red spring. If more or less tension is needed, release the toggle clamp, adjust the nut on the threaded rod that penetrates the spring. A compression to 2" in height will be sufficient even for very heavy gates. Slightly less compression should be used for gates that weigh under 1000 pounds, or roll very easily. 2 1/8" compression is the maximum for the 111 LS operator.

12. Adjust the lever arms of limit switches to maintain at least 1/4" clearance from the underside of the drive rail. This will avoid false tripping of the limits (see drawing# S 22). The limit switch arm should be approximately in the center of the rail channel. **If adjustment is required, remove the limit arm before bending.** This will avoid breaking the head of the switch. Locate the plastic limit ramps on the underside of the drive rail to control maximum travel of the gate in the open and close direction. Mount the limit ramps to trip the limit switches approximately three inches ahead of the desired gate stopping position. This clearance is needed for gate deceleration travel, after the limit switch has been tripped.

13. Check the "soft stop" open timer, which is mounted on top of the control relay. The label on the timer dial shows the minimum and maximum settings. In operation the timer only needs to be set long enough for the gate to coast to a smooth stop after opening. There is no bad effect if the timer is set for too long, except that the operator cannot be started closed until this timer times out. There is no timer adjustment for the close direction.

14. Set the maximum run timer, which is located at the extreme right, inside of the electric panel. The range is adjustable to 10 minutes. Set the timer for more than twice the amount of time needed for the gate to traverse the opening.

ADJUSTMENT OF ACCESSORIES AND INFORMATION ABOUT TWO FOOT/SECOND OPERATORS

1. Set "timer to close" accessory for desired delay. This optional timer is located on the left side of the main control relay. The range is adjustable from 1 to 30 seconds. The timer will close the gate from any position, but all open and safety signals must be absent.

2. All operators, except 111 LS and 222 SS, have a reverse delay timer mounted at near center of the control panel. The delay is adjustable from .3 to 3 seconds, and works together with the soft stop feature to provide smooth reversing. Larger gates will need a longer delay to allow time for the momentum of the gate to be stopped. Most gates will only need a second or less. The time needed to stop and reverse a gate is partly a function of the optional brake valves that are included with many models. See number three for their correct adjustment.

3. All two foot per second operators, as well as any operator that is intended to drive gates in excess of 1,000 pounds should be equipped with the "E" option, which adds a reverse delay and hydraulic brakes, to rapidly decelerate a gate. The positioning of the limit ramps should be 6 inches ahead of full gate travel to give some space for deceleration. Adjustment of the brake valves, one for each direction, affects the limit switch adjustment. If adjustment is necessary, loosen the 9/16" lock nut on the end of the brake valves (located on the front side of the hydraulic pump). Turn the adjustment stem with an allen wrench. The adjustment works opposite of typical, in that a counter-clockwise adjustment will stop the gate more rapidly. If the adjustment is set too loose, the gate will coast too far. If the adjustment is set too tight the gate speed will decrease. Be certain to re-tighten the locking nut when the adjustment is complete.



Hy-Security Gate Operators

Phone: 1-800-321-9947 • Fax: (206) 286-0614 • Web: www.hy-security.com • 1200 W Nickerson St • Seattle, WA. 98119

Use and Adjustment of the Manual Release Mechanism


All slide gate series operators come equipped with a toggle handle manual release mechanism to disengage the drive wheels from the drive rail. The manual release is located under the electric control panel and to the right of the hydraulic motors. To disengage the drive wheels, simply pull the aluminum handle down.

USE CAUTION: at first the toggle handle will rapidly pop down, as the loaded spring releases. This action will cause the lower drive wheel to drop and disengage from the drive rail. When the coupling nut on the threaded rod drops to its lowest position it will push on the base of the operator which will cause the upper drive wheel to lift and disengage from the drive rail.

For shipment, a piece of wood was placed between the coupling nut and the chassis. If the wood is still in place, discard it.

If the drive rail has been installed at the correct height to the chassis, the manual toggle release mechanism will equally spread both wheels away from the drive rail. If the rail has been mounted higher than specified, it may be necessary to insert a 3/8" bolt into the bottom of the coupling nut which will create additional lift clearance for the upper drive wheel when manually released. If used, adjust the 3/8" bolt so the drive wheels spread equally when the manual toggle release is fully disengaged.

The coupling nut must always be adjusted correctly so the wheels provide a strong clamping force on the drive rail. The red spring should measure 2" to 2-1/8" in height when under correct compression.



For assistance call your Distributor.



Wire Size Schedules for 1/2-hp through 5-hp motors

Supplying a gate operator with the right electrical service is crucial to the way the performance of the operator the life of its electrical components. If the wire size used is too small, the voltage loss—especially during motor starting—will prevent the motor from attaining its rated horsepower. The percent of horsepower lost is far greater than the percentage of the voltage loss. A voltage loss could also cause the control components to chatter while the motor is starting, substantially reducing their life due to the resultant arcing. There is no way to restore the lost performance resulting from undersized wires, except to replace them; therefore it is much more economical to choose a sufficient wire size at the initial installation.

The tables on the following page are based on copper wire and allow for a 5% voltage drop. The ampere values shown are the service factor ampere rating (maximum full load at continuous duty) of the motor.

Always connect in accordance with the National Electrical Code, article 430, and other local codes that may apply.

The maximum distance shown is from the gate operator to the power source; assuming that source power is from a panel box with adequate capacity to support the addition of this motor load. The values are for one operator, with no other loads applied to the branch circuit. For two operators applied to one circuit, reduce the maximum allowed distance by half.

Use this chart to determine maximum allowable control wiring distance. If the location required exceeds the distances listed on the chart at the right, addition of a long range interface will be necessary.

<i>Pushbutton Control Wiring</i>	
<i>16 ga</i>	<i>125' Maximum</i>
<i>14 ga</i>	<i>200' Maximum</i>
<i>12 ga</i>	<i>300' Maximum</i>
<i>10 ga</i>	<i>500' Maximum</i>

Wire Sizes for Power Wiring, Single Phase Distances are shown in the unshaded boxes

Wire Gauge	115 V, SINGLE PHASE						208 V, SINGLE PHASE						230 V, SINGLE PHASE						
	Amps	10.0	11.06	14.4	27.2	NA	NA	5.5	6.1	7.6	14.2	16.2	NA	5.0	5.8	7.2	13.6	14.8	27.0
	Horse Power	1/2hp	3/4hp	1hp	2hp	3hp	5hp	1/2hp	3/4hp	1hp	2hp	3hp	5hp	1/2hp	3/4hp	1hp	2hp	3hp	5hp
12ga	90	75	60	30				290	260	205	110	100		350	300	245	130	120	65
10ga	140	120	100	50				460	415	330	175	155		560	480	385	205	190	105
8ga	220	190	155	80				725	650	525	280	245		880	760	610	325	300	165
6ga	350	300	245	130				1,150	1,040	835	445	390		1,400	1,120	975	515	475	260
4ga	555	480	385	205				1,825	1,645	1,320	710	620		2,220	1,915	1,550	815	750	410
2ga	890	765	620	330				2,920	2,630	2,110	1,130	1,000		3,550	3,060	2,465	1,305	1,200	660

Wire sizes for Power Wiring, Three Phase Distances are shown in the unshaded boxes

Wire Gauge	208 V, THREE PHASE						230 V, THREE PHASE						460 V, THREE PHASE						
	Amps	2.7	3.1	4.2	6.5	6.7	16	2.4	3.0	3.8	6.2	6.4	15.4	1.2	1.5	1.9	3.1	3.2	7.7
	Horse Power	1/2hp	3/4hp	1hp	2hp	3hp	5hp	1/2hp	3/4hp	1hp	2hp	3hp	5hp	1/2hp	3/4hp	1hp	2hp	3hp	5hp
12ga	590	510	375	245	235	100		730	585	460	280	270	115	2,915	2,350	1,850	1,130	1,100	455
10ga	930	810	600	390	375	160		1,160	930	730	450	435	180	4,640	3,710	2,930	1,800	1,740	725
8ga	1,475	1,285	950	615	595	250		1,835	1,470	1,160	710	690	285	7,340	5,870	4,650	2,840	2,750	1,150
6ga	2,350	2,045	1,510	975	945	400		2,925	2,340	1,845	1,130	1,095	455	11,700	9,350	7,400	4,550	4,400	1,800
4ga	3,720	3,240	2,390	1,545	1,500	630		4,625	3,700	2,920	1,790	1,735	720	18,500	14,800	11,700	7,200	7,000	2,900

Always connect in accordance with the National Electrical Code, article 430, and other local codes that may apply.



Hy-Security Gate Operators

Phone: 1-800-321-9947 • Fax: (206) 286-0614 • Web: www.hy-security.com • 1200 W Nickerson St • Seattle, WA. 98119


Wire Size for Voltage Drop Over Distance

Wire Gauge

Wire Gauge

E16b

NOTE
 WHEN USING A FREE DETECTOR TOGETHER WITH AN OBSTRUCTION DETECTOR, INSTALL A JUMPER WIRE FROM THE FREE DETECTOR SOCKET PIN #10 DIRECTLY TO THE OBSTRUCTION DETECTOR SOCKET PIN #6 AND OMIT THE CONNECTION FROM THE OBSTRUCTION DETECTOR PIN #6 TO TERMINAL #1. SEE DETAIL OF OPTION A IN DRAWING E85T AND NOTE 1 IN DRAWING E63T2.



INSTALLER NOTE: IT IS EXTREMELY IMPORTANT TO VERIFY INCOMING PRIMARY LINE VOLTAGE AND TO MAKE SURE IT IS CONNECTED TO THE MATCHING PRIMARY TAP ON THE TRANSFORMER. THIS IS ESPECIALLY IMPORTANT ON 208V AND 230V MACHINES.

WIRE #	WIRE COLOR
1	BLUE
1A	WHITE
2	RED/YEL STRP
3	GREEN
4	BROWN
5	WHT/RED STRP
6	ORANGE
7	YELLOW
8	GREY
9	VIOLET
10	RED/WHT STRP
11	RED
12	BLACK
13	BLU/WHT STRP
14	WHT/BLK STRP
15	GRN/WHT STRP
16	BLK/WHT STRP
17	BRN/WHT STRP
18	ORG/WHT STRP
19	YEL/BLK STRP
20	YEL/BLK STRP
21	GRN/BLK STRP
22	BRN/BLK STRP
23	ORG/BLK STRP
24	YEL/RED STRP
25	YEL/RED STRP
26	GRY/RED STRP
26A	WHT/BLK STRP


BE CERTAIN TO JUMPER 2-4 IF AN EXTERNAL STOP IS NOT USED.





TITLE:
ELECTRICAL COMPONENTS
 HRG, 444, 333, 222 (ALL MODELS EXCEPT CF, HS OR DC VERSIONS)

DATE: 12/3/98
 REV. NO: 1
 REV. DATE: 5/22/00

PART NUMBER: N/A
 PAGE 1 OF 1
 DRAWING NUMBER: E20T2





NOTE:
 WIRING FOR ALL REMOTE 24 VAC CONTROL
 PUSHBUTTONS. EXCEPT HTG 320.
 SINGLE BUTTON STATION REQUIRE 4 CONDUCTORS.
 FIRST STATION IN MULTIPLE STATION GROUP
 REQUIRES FIVE CONDUCTORS (SEE EXAMPLE).

NOTE:
 ON MULTIPLE STATIONS BE SURE TO CUT JUMPER
 (CLOSE TO STOP) IN FIRST STATION AND ADD WIRE
 BETWEEN THE TWO STOP BUTTONS.

SINGLE BUTTON STATIONS
 EXCLUDING OPERATOR MOUNTED



MULTIPLE BUTTON STATIONS
 EXCLUDING OPERATOR MOUNTED



THE NUMBERS IN THE CIRCLES ARE WIRES THAT CORRESPOND TO THE CONTROL CIRCUIT. CONNECT
 THE PUSHBUTTON STATION TO THE TERMINAL STRIP INSIDE THE CONTROL BOX. MATCH WIRE NUMBER
 TO THE TERMINAL NUMBER.




TITLE
**REMOTE 4 WIRE
 PUSHBUTTON WIRING**

DRAWN DB	DATE 05/04/00	THIRD ANGLE PROJECTION 		REV A
CHECKED -	DATE -	ERN NUMBER -	DATE -	
APPROVED -	DATE -	DRAWING NUMBER E57		SHT OF




Electrical Circuit Options Applies to all operators except HTG 320 models

A Any Open Device or Free Detector




Any device used to open the gate, such as a pushbutton, key switch or detector, connects to #1 to #4. The gate will be held in the open position if contact is maintained.

B Closing Obstruction Sensor




This input allows connection of an obstruction sensor to guard the closing of a gate. Connect the sensor output to #1 and #6. If the sensor is a vehicle detector and is used with a free detector, connect the N.O. of the obstruction detector to the N.C. of the free detector, as shown at left. If tripped while closing, the gate will reverse to the full open position.

C Opening Obstruction Sensor



This input allows connection of an obstruction sensor to guard the opening of a gate. If tripped while opening, the gate will reverse slightly, and then self-disable for two seconds. Connect a N.O. contact (edge sensor or photo eye) to terminals #6 and #9.


D Open/Close Interface



This special interface allows one contact, two-way control: the gate can be closed only after opening fully, but can be opened from any position. For 222SS models only, option D must be ordered with option E, Reverse Delay. Refer to the connection diagram for detailed wiring information.


E Reverse Delay

—not available on 111LS—
standard with all operators
except 222SS




This option delays start in the open direction. It is also used to delay instant reverse. It can be added by itself or as part of several factory modifications necessary to convert operators to 'E' type. Remove the jumper between #1 and #7 when installing the reverse delay.

F Interlock & Relay




To interlock two Hy-Security machines connect a N.O. pole of the 'F' relay to the other operator (in all but the 111LS), and remove the jumper between #1 and #1A. In the 111LS, remove open limit wire #8 and wire in series with 'F' relay N.O to #8.

G Shadow Detector



Swing gates require an additional loop and detector for the area under the arc of the gate. This detector can hold the gate when open, but is turned off when the gate begins to close.

H Heater



We recommend a heater be installed in colder climates; use one rated for the supplied voltage. Connect to terminals L1 and L3 of the motor starter. On 480 VAC systems an additional relay is required.



Hy-Security Gate Operators

Phone: 1-800-321-9947 • Fax: (206) 286-0614 • Web: www.hy-security.com • 1200 W Nickerson St • Seattle, WA. 98119

Long Range Pushbutton Control Connection Diagram

Voltage loss over distance is caused as a function of control amperage multiplied by the resistance of the wiring, and may be expressed: **Voltage loss = (wire resistance) X (control amperage)**. This limits pushbutton control wiring to the following schedule:

16 ga. wire = up to 125 feet max 12 ga. wire = up to 300 feet max
14 ga. wire = up to 200 feet max 10 ga. wire = up to 500 feet max


For applications requiring pushbutton controls from a long distance, or circuits of limited current, order the factory modification, long range interface. The following schedule indicates the improved control range using the long range interface:

16 ga. wire = up to 50 miles 20 ga. wire = up to 19 miles
18 ga. wire = up to 30 miles 22 ga. wire = up to 12 miles

**FOR BEST PERFORMANCE
USE 20 GAUGE WIRE OR LARGER**

Be certain to remove factory-installed jumper (#2 to #4) and also verify that no other external stop button is connected at #2 and #4.

When the long range interface option is used in conjunction with a pushbutton control, connect to the operator as shown below:



NOTE:
The part number for the long range interface, installed at the factory, **A EIF 001 OCS**
The same part designation for the long range interface, in kit form, **A EKIF 001 OCS**



Hy-Security Gate Operators

Phone: 1-800-321-9947 • Fax: (206) 286-0614 • Web: www.hy-security.com • 1200 W Nickerson St • Seattle, WA. 98119

Master/Slave Interconnection Instructions

FOR ALL MODELS EXCEPT: HTG 320

Operation of two Hy-Security gate operators as a master/slave pair is simply a matter of correctly interconnecting the two control circuits. Join the following four wires from the master operator to the slave:

Terminal #1 master to terminal #1 slave,
Terminal #3 master to terminal #3 slave,
Terminal #4 master to terminal #4 slave,
*Terminal #10 master to terminal #10 slave

All stop control inputs must be connected to the master operator only. The slave operator must not have any connection between terminal #2 and terminal #4, such as a stop button or jumper.

*On DC battery powered operators, interconnect the black wires (-) to the on/off switch instead of the #10 wires. This prevents one operator from powering the other when the disconnect switch is off.

For assistance call your Distributor.



Installation Instructions For Gate Reversing Sensing Edge

1. Securely bolt the edge sensor to the edge of the gate. The edge should line up with the lower corner of the gate frame.
2. If the reversing edge is to wire directly to the gate operator:
 - A. Locate a mounting position for a curl cord attachment, or retracting cord reel holder where there will be no possibility of the cord rubbing on the moving gate panel.
 - B. Attach the cord to the gate in a position that is roughly near the position of the automatic operator, when the gate is closed.
 - C. Route the wires to the leading edge of the gate and join to the wires of the reversing edge. Wirenut and thoroughly tape the connections so that they are not prone to vibrate loose.
 - D. Join the fixed end of the cord reel or curl cord directly to terminal numbers 1 and 6 inside the control box of the operator.
3. If the reversing edge is to transmit to the gate operator:
 - A. Mount the reversing edge transmitter (Multi Elmac Model #3022, or equivalent) onto the gate panel near the upper corner of the leading edge of the gate.
 - B. Join the wires of the reversing edge to the two terminals inside of the edge transmitter. Set a unique code on the “DIP” switches inside the transmitter. Remount the cover of the transmitter and tighten the screws firmly so that no water will leak inside.

If a receiver for the reversing edge has been prewired inside the operator, proceed directly to step #3D.

 - C. Mount a commercial style radio receiver* (one with a connector for an external antenna) on the inside of our operator enclosure. Connect the 24 Volt supply wires to terminal numbers X1 and 10 on the terminal strip. Connect the radio contact wires to terminal numbers 1 and 6 on the terminal strip.
 - D. Mount an external antenna onto the top of a fixed post of the fence near the operator. Connect the antenna into the socket on the radio receiver.
 - E. Set the “DIP” switches in the receiver to match the same code used in the edge transmitter.

*If there is also to be a radio receiver for a hand held transmitter to operate the gate, be certain to use a two channel commercial receiver.
4. Test the operation of the reversing edge to be certain that it is functioning. Advise the user of the gate to be certain to retest this vital function weekly.

Photoelectric Eye, Reflector Adjustment Instructions

Correct installation and alignment of a retro-reflective photo eye and its reflector are important for a trouble free installation. Systems operating at a range of 15' or more are prone to weather caused reductions in range. We feel that if care is taken in the initial mounting and alignment of the 13" reflector then the chance of problems is greatly reduced. Taking steps to protect the reflector from being exposed to fog and being absolutely certain the photo eye is perfectly aligned will greatly increase the apparent power of the photo eye.

The ideal mounting for the reflector is suspended inside a 12" long piece of 3" P.V.C. conduit. Cut the opening of the 3" P.V.C. conduit at a 45 degree angle to act as a drip shield. The reflector is held against the backside of the 3" conduit by attaching a 3" male connector. Do not cement the connector so that the reflector can be reached for future cleaning. To create a mounting base, attach a 3" aluminum meter hub or flange to the connector. The whole package can now be mounted to any flat surface.

Locating the reflector in the center of the invisible beam of infrared light is important to achieve the most sensitive alignment. The center is determined by the following test. While holding the reflector in your hand, slowly raise it until the beam is no longer returned and the photo eye trips. Mark this maximum height. Now lower your hand and determine the lower limit of the infrared beam by watching the trip point. Mark this position well. Repeat the same procedure for left and right at the center elevation of the beam, as determined by the previous test. Once the four limits have been determined, either mount the reflector in the center of the area outlined or realign the eye for the position of the reflector. If the photo eye is realigned, be sure to perform the centering test again to verify that the reflector is truly in the center.

As a last tip, smearing dish soap on the reflector will also help to repel any possibility of fogging from moisture that gets into the 3" pipe. With all of these steps taken, the optimum performance of the retro-reflective photo eye system will be achieved.

Note: To cover greater distances, or to operate in adverse weather conditions, consider a through-beam photo eye.

For Assistance call your Distributor.

Detector Installation Guide

Loop Basics

The vehicle detector passes a small current flow through the “loop” which then becomes an inductive coil. When a vehicle passes over a loop the detector senses the resultant drop in the inductance, and actuates it’s output relay.

Loop Configurations

Configurations differ depending on the application. In parking applications with our HTG320 operator, a loop may be as small as 3’ x 6’. In traffic applications employing one of our sliding gate operators, or swing gate operators, the smallest loop should not be less than six feet square.

Rules to Follow for Security Gate Applications

1. The side of the loop closest to the gate shall be located at least four (4) feet distant from it’s line of travel.
2. The shortest side of the loop shall be between six (6) and eight (8) feet in length. The longest side of the loop shall be between six (6) and twenty (20) feet in length. For applications that need to span a wide area, use several smaller loops. Do not exceed a maximum of 200 square feet of loop area to only one detector.
3. In applications with multiple loops, keep each loop at least six feet apart. This avoids “cross talk”. It is possible to have loops closer together by selecting different frequencies.
4. For greater sensitivity and less chance of false calls caused by the motion of the gate, it is better to use two smaller loops, connected in a series circuit, to one detector instead of one large, single loop.
5. To avoid interference, keep loops at least two (2) inches above any reinforcing steel. Do not route loop wires with, or in close proximity to, any other conductors, including other loop leads, unless shielded lead-in cable is used.
6. Loop and lead-in wire should be one continuous piece. Avoid splices, if possible. If a splice is necessary for any reason, “pot” the splice in epoxy or use heat shrink to ensure that the quality of the splice covering is the same as the original wire jacket.
7. Use only number 12, 14, or 16 gauge stranded wire with a direct burial jacket. Cross linked polyethylene insulation types, such as, XLPE or XHHW, will last much longer and are less prone to damage during installation than conventional insulation types. Preformed loops can be used before road surfacing or under pavers.
8. Twist loose tails of lead-in wires tightly, approximately ten times per foot.


Twist lead-in at least 10 turns per foot



Like This



Not Like This



4/13/00


E31a

continued from previous page...

9. Follow this guide for the correct number of turns in the loop;

12 to 20 sq. ft = 5 turns 20 to 60 sq. ft. = 4 turns 60 to 240 sq. ft. = 3 turns

10. This guide is written from a design perspective, but installation workmanship practices are equally important to insure proper operation and long loop life. The best way to insure a quality installation is to employ a professional installer experienced with detector loops. A few important practices are: **A.** The slot in the surface should be cut ¼” wide x 1 ½” deep. **B.** The corners of the cut must be at an angle or core drilled to relieve stress on the wires. **C.** After the wire is installed, the slot must be completely backfilled with a non-hardening sealer. Note that if the loop wires are able to move in the slot after the sealer has set, the detector may give false calls.



Detector Logic

Hy-Security Gate Operators recommends that vehicle detectors be used for free open and obstruction sensing logic only. The exception is in parking applications with our HTG320 operator where detectors may be also used to close the gate. In applications employing our swing , vertical lift, or sliding gate operators, closing logic cannot be used. Because of their slower speeds, closing logic is a poor choice for security gate systems. Since there are several ways that the gate may be left standing open and because there is a loss of safety. Our circuit has not been designed to accomodate “detect to close” logic.

Loop Diagnostics


The following tests cannot guarantee a functioning loop, but failure of either test means that the loop is definitely suspect, even though it may still be functioning at the time.

Test #1:

Resistance of the loop and lead-in wire should not exceed 4.0 Ohms.

Test #2:

The resistance to earth, as measured with a 500V “Megger”, should be 100 Megohms or more. Loops may function at 10 Megohms or less but will not be reliable (e.g. when the ground is wet from rainfall). Low resistance indicates broken or moisture saturated insulation. This is common if inappropriate wire insulation has been used.



TITLE
SLIDE GATE LOOP LAYOUT

DRAWN DB	DATE 05/15/00	THIRD ANGLE PROJECTION 	
CHECKED -	DATE -	ERN NUMBER -	DATE -
APPROVED -	DATE -	DRAWING NUMBER E96	

REV
A

SHT | OF |
 | |



Hy-Security Gate Operators

Phone: 1-800-321-9947 • Fax: (206) 286-0614 • Web: www.hy-security.com • 1200 W Nickerson St • Seattle, WA. 98119

Operator Maintenance Hydraulic System

Fluid Level: Under normal conditions, hydraulic systems do not consume oil. Before adding any oil, check the system thoroughly for leaks. Remove the bright metal plug in the tank, fill to plug level, then replace plug. We recommend our *Uniflow* hydraulic oil, part number H-004, which is sold in one gallon containers by our distributors. Automatic transmission fluid may be used, although its performance in cold weather will be sluggish unless the operator is well heated. *Do not use brake fluid.*

Look for leaks: Occasionally there may be slight seeping at the fittings after some usage. Tightening of the fittings will usually correct the problem. If the leaking persists, replace "O" rings, fittings or hoses, if required. No further leaks should occur.

Oil Change: A hydraulic system does not foul its oil, unlike a gas engine, so oil changes do not need to be frequent. Rather, heat breakdown is the main concern in a hydraulic system. If the unit is subjected to high use, especially in a warm climate, change the oil more frequently. In general, we recommend draining the reservoir and replacing the oil at five or ten year intervals.

There are several ways to change the hydraulic oil, depending on the type of operator being serviced. If you don't know how to drain the oil, contact your distributor for directions. Refill with new *Uniflow* hydraulic oil (available from your distributor). To avoid overfilling, never pour into the port where the black breather cap is located. Instead, remove only the bright metal plug in the tank. Slowly pour the oil into the tank until the oil is within one inch of the filler port. Replace the plug and wipe up any spilled oil.

Cold Weather:

1. Check that your reservoir is filled with *Uniflow* high performance oil.
2. Ice can partly or totally jam gate operation. Check by operating the gate manually.

Electrical Controls

Before servicing, turn off power disconnect switch

No routine maintenance is needed for the electrical system or controls. If the environment is very sandy or dusty, seal all holes in the electrical enclosure. Blow dust out of the electric panel with compressed air. A qualified electrician may troubleshoot with the aid of the electrical drawings in Appendix 4.

If it is necessary to call a distributor for assistance, be sure to have your model and serial number ready. Other helpful information would include the name of the job, approximate date of installation, and the service record of the operator, especially any work that has been done recently. Be prepared to describe as exactly as you can what the machine is or is not doing. Describe any unusual sounds or location of oil leaks.

How to Adjust the Pressure Relief Valve: To check your relief valve setting, first disconnect one of the hoses. Run the operator either open or closed (the gate will not move with the hose disconnected). The relief valve is found on the rear of the hydraulic power unit. It has a hex adjusting head and lock nut. To adjust, loosen the lock nut and screw the threaded bolt clockwise for increased pressure, counterclockwise to decrease pressure.

MODEL	FACTORY SETTING
111 Series	750 psi
SS, E Models	1000 psi
EX Model	1300 psi
444 Series	1300 psi

Do not attempt to use the relief valve as an entrapment protection device. Photocells or gate edges are the best methods to protect pedestrians and reserve power to the drive gate.



Hy-Security Gate Operators

Phone: 1-800-321-9947 • Fax: (206) 286-0614 • Web: www.hy-security.com • 1200 W Nickerson St • Seattle, WA. 98119

SLIDE GATE OPERATOR MAINTENANCE SCHEDULE

NAME OF PART	WHAT TO DO		CHECK AT THESE RECOMMENDED MONTHLY INTERVALS					
			1	3	6	12	120	
Gate and Hardware	Check for damage and wear	*1	X					
Drive Wheels	Check for excessive wear	*2		X				
Wheel clamp spring	Check clamping tension	*3		X				
Limit switches	Check adjustment	*4		X				
Anchor bolts	Check for tightness				X			
Fluid level	Check for loss of fluid	*5				X		
Hydraulic fluid	Drain and replace fluid							X


Special Notes:

- *1 Your gate and it's hardware will require more maintenance than the Hy-Security operator that is moving the gate. A damaged gate or worn hardware may cause operation to appear slow or erratic and will result in excess drive wheel wear. Lubricate the gate hardware more frequently and check for smooth operation by opening the toggle clamping mechanism and then pushing the gate manually. One person should easily be able to push all but the largest of gates. Damaged or warped gate panels should be straightened or replaced.
- *2 Normally, the drive wheels will last for many years because they are designed to not slip on the rail. The life of the wheels may be greatly shortened by any of these faults: clamping spring not correctly adjusted, operator misaligned in relation to gate panel, badly warped gate panel or extremely stiff hardware.
- *3 111 LS Series and 222 SS series have similar requirements. Verify that the red clamping spring is compressed tightly, so that the drive wheels apply a strong grip on the power rail. The red spring should normally be compressed to 2" in height.
- *4 The limit switch rollers should ride ¼" to ½" below the drive rail, near the center of the channel. Misadjustment may result in false or early tripping or no limit function at the end of travel. Verify that the limit trip ramps are tightly bolted to the drive rail.
- *5 The oil level should remain approximately one inch below the filler hole. See maintenance instructions for oil filling. Loss of fluid is not normal and indicates a leak that must be located and repaired. The cap for the filler hole is a breather and needs only to be finger tight. Use "Uniflow" fluid, part H 004, if additional fluid is required.




Hy-Security Gate Operators

Phone: 1-800-321-9947 • Fax: (206) 286-0614 • Web: www.hy-security.com • 1200 W Nickerson St • Seattle, WA. 98119




Pressure Relief Valves Adjustment Procedures



RELIEF VALVE

Side View

<u>Model</u>	<u>Factory Setting</u>
111 Series	750 psi
222 SS, E	1000 psi
222 EX	1300 psi
444 Series	1300 psi
HRG Series	1300 psi
HVG Series	2000 psi
HTG 360	1000 psi
HTG 320-6	1000 psi
HTG 320-3	1000 psi
HTG 320-2	700 psi



GAUGE PORT

Front View

The relief valve can be found on the back side (gate side) of the hydraulic power unit. It is the only component located here and has a hex adjusting head and lock nut. To adjust setting, loosen the lock nut screw the threaded bolt CW for increased pressure, turn CCW to decrease pressure.

Pressure relief valves are preset at the factory to utilize maximum available horsepower. The relief valve can be lowered to smooth starting if necessary. This is most easily done by decreasing the pressure until the gate operation slows, and then increasing the pressure just enough to provide normal gate speed.

It must be understood that if you reduce the pressure setting, you will lose horsepower to move the gate if additional resistance (old gate hardware, snow and ice, etc.) is encountered.

Do not attempt to use the relief valve as an entrapment protection device. A photo eye or a gate edge is the best method to protect pedestrians and reserve power to drive the gate.




Hy-Security Gate Operators

Phone: 1-800-321-9947 • Fax: (206) 286-0614 • Web: www.hy-security.com • 1200 W Nickerson St • Seattle, WA. 98119

Troubleshooting Guide - Slide Operators

Trouble With Gate Movement, in General:

1. For adequate traction, the red spring that clamps the drive wheels must be compressed to $2\frac{1}{8}$ " - 2". (Include the portion of the spring that is hidden in the spring retainer, when measuring compression.)
2. Look inside the chassis under the wheels for metal shavings. This might indicate that the machine or the gate panel are out of alignment. Realign operator or drive rail as necessary.
3. Check for smooth operation of the gate by disengaging the drive wheels and pushing the gate manually.



Electrical Problems in General:

1. Check Overload Reset button in lower right-hand corner of control enclosure.
2. Check Transformer Reset button.
3. Reset Maximum Run timer by turning off power or pressing the Stop button.
4. Measure and record the actual line voltage supply, while the operator is running.
5. Disconnect accessories like access controls, detectors and photocells, and recheck function.

Other Problems:

"I pushed the button, but nothing runs."

1. Verify that the line voltage is correct, and on three phase machines verify that all phases are working.
2. You may need to reset the control circuit breaker on the transformer.
3. Be sure control voltage is approximately 24 volts. Measure voltage between terminals #2 and #10 on 111 LS and #X1 and #10 on 222SS & EX. Reset the circuit breaker if control power is absent. Check the transformer primary tap if control voltage is incorrect.
4. Check overload (red button in electrical enclosure) by pushing the button in.
5. Be sure the limit switch levers are at least one quarter-inch below the drive rail so the levers won't trip accidentally.
6. Check for a jumper from #2 to #4, if an external stop button is not used.
7. Check the wire size schedules for maximum allowable length of control wiring runs to verify that voltage drop is not a problem.

"The pump is running but the wheels are not turning."

1. If the power is three phase, reverse any two of the three lines to correct rotation direction of the electric motor.
2. Check the level of hydraulic oil by removing the plug in the reservoir. Add oil, at this location, to within one inch of the hole that contained the plug.
3. If the hydraulic hoses are connected with quick disconnects, be certain that the connections are fully seated.
4. Read the pressure on the gauge to verify that the pump is set to deliver sufficient pressure. See the pressure relief valve adjustment page.

"The wheels turn backwards, or only in one direction."

1. Check hose connections for correct handling.
2. Verify that electrical fitting to hydraulic valve is coil is functional by attempting to slide it off the valve stem while the system is activated in the open direction.
3. If the gate only opens, chances are the solenoid is stuck, clean or replace the valve.



Conversion of Primary Operator Voltage

These instructions do not apply to conversions from single phase to three phase or vice versa. Conversion from one phase to another is not recommended.

Steps required to convert the voltage of an operator within the same phase:

1. *The overload must be changed to match the motor current at the new operating voltage.*

To do this, remove the overload device from the contactor by loosening the three screws T1, T2 and T3 on the contactor. Remove all the wires on the overload and replace them exactly the same position on the new overload. Mount and tighten screws firmly. Be certain the new overload is adjusted to match the motor nameplate amps that correspond to the new voltage. Note that the existing overload has sufficient range to accommodate adjustment from 208 volts to 230 volts or vice versa.

2. *The primary tap on the control transformer must be changed to the new voltage.*

This is accomplished by first reading the label on the top of the control transformer to determine which color primary lead corresponds to the new voltage to be used. Disconnect the existing primary lead (**Caution:** Do not disconnect the primary “Common” lead) and reconnect the primary lead to the same location.

3. *The power leads to the motor must be reconnected in the motor junction box to match the new voltage.*


You must remove the cover from the junction box on the electric motor. Reconnect the primary leads in the new configuration shown on the motor nameplate that matches the new voltage. Note this step does not need to be performed for conversion between 208 volts and 230 volts.

4. *The operator must be re-labeled to indicate the new voltage.*

Apply new labels to the operator so that the correct primary voltage is indicated.

5. To add a heater you need the following parts: (includes thermostat wire and all mounting hardware):


120 VAC	AEKHE 120 250
208-240 VAC	AEKHE 240 250
480 VAC (includes relay)	AEKHE 480 250




TITLE
**COMPONENTS MANUAL RELEASE
 TOGGLE ASSEMBLY FOR
 ALL SLIDE GATE OPERATORS**

DRAWN D. B.	DATE 05/12/00	THIRD ANGLE PROJECTION 		REV
CHECKED -	DATE -	ERN NUMBER -	DATE -	A
APPROVED -	DATE -	DRAWING NUMBER: S24		

SHT	OF
1	1



FRONT VIEW



SIDE VIEW



ITEM #	QTY.
1-1	EMOMO 010 1.0B 1 EA
1-2	EMOMO 030 1.0B 1 EA
3-1	HVASO DEL 024 1 EA
3-2	ECOPL 001 1 EA
3-3	HSFFI CSP 06 1 EA
3-4	HVARE FBN 1 EA
3-6	HSFOD 002 S 2 EA
3-7	HRSRS 004 1 EA
3-8	HVACK 003 1 EA
3-9	HSFFI 686 0402 2 EA

ITEM #	QTY.
3-11	HRSBC 001 1 EA
3-12	HVADI DEL 2P 1 EA
3-13	HSFFI 714 CS04 2 EA
3-14	HPPPU H12 1 EA
3-17	MPTCO 010 9T 1 EA
3-18	HASGA 120 MINI 1 EA
3-19	HVAQS 001 C 1 EA
3-20	HVASO DEL QSAC 1 EA



TITLE
COMPONENTS, HS-12 POWER UNIT FOR 222 SS, 222 CF, 333 MS

DRAWN KERI	DATE 6/16/00	THIRD ANGLE PROJECTION 	REV --
CHECKED SHOP	DATE MM/YY/DD	PART NUMBER N/A	
APPROVED ENGRNG	DATE MM/YY/DD	DRAWING NUMBER: S46	SHT OF 1 1




ITEM #		QTY.
1-1	EMOMO 010 1.0B	1 EA
1-2	EMOMO 030 1.0B	1 EA
3-1	HVASO DEL 024	1 EA
3-2	ECOPL 001	1 EA
3-3	HSFF1 CSP 06	1 EA
3-4	HVARE FBN	1 EA
3-6	HSFQD 002 S	2 EA
3-7	HSRS 004	1 EA
3-8	HVACK 003	1 EA
3-9	HSFF1 714 CS04	1 EA

ITEM #		QTY.
3-11	HSBC 001	2 EA
3-12	HVADI DEL 2P	1 EA
3-13	HVABK CBA 1500	1 EA
3-14	HPPPU H12	1 EA
3-17	HMAMA 222 BVK	1 EA
3-18	HASGA 120 MINI	1 EA
3-19	MPTCO 010 9T	1 EA
3-20	HVAQS 001 C	1 EA
3-21	HVASO DEL QSAC	1 EA




TITLE
**COMPONENT HS-12 POWER UNIT FOR
 222 E, 222 CE, 333 E**

DRAWN KERI	DATE 6/23/00	THIRD ANGLE PROJECTION 	REV --
CHECKED SHOP	DATE MM/YY/DD	PART NUMBER N/A	
APPROVED ENGRNG	DATE MM/YY/DD	DRAWING NUMBER: S49	SHT OF 1 1




SIDE VIEW

BACK VIEW




FRONT VIEW



ITEM #	QTY.
1-1	EMOMO 010 2.0B EA.
1-2	EMOMO 030 2.0B EA.
3-1	HMAAC 011 H EA.
3-2	ECOPL 001 EA.
3-3	HSFFI CSP 06 EA.
3-4	HVARE LAN EA.
3-6	HSFOD 002 S 2 EA.
3-7	HRSRS 004 EA.
3-10	HVABK CBA 1500 2 EA.
3-11	HRBC 001 EA.
3-12	HVADI DEL 2P EA.
3-13	HSSFI 714 CS04 EA.
3-14	HPPPU H13 EA.
3-15	HMAAC 111 SSK EA.
3-16	HASGA 120 MINI EA.
3-17	HMAMA 222 BVK EA.
3-18	HVASO DEL 024 EA.
3-19	MPTCO 010 9T EA.
3-20	HVAQS 001 C EA.
3-21	HVASO DEL QSAC EA.

	TITLE	DRAWN	DATE	THIRD ANGLE PROJECTION	REV
	HS-13 POWER UNIT W/ SOFT START FOR 222 EX, 222 X1, 222 CX, 333 MX	KERI	6/16/00		--
		CHECKED	DATE	PART NUMBER	
		SHOP	MM/YY/DD	N/A	
	APPROVED	DATE	DRAWING NUMBER:	S47A	SHT OF
	ENGRNG	MM/YY/DD			1 1



ITEM #	QTY	
2-1	ESWLS 224 LONG	1 EA.
2-2	ESWLS 224 SHRT	1 EA.
2-3	ESWDL 050 3P	1 EA.
2-4	ECOTS 020	1 EA.
2-5	EECTI 024 30S	1 EA.
2-6	EECTI 024 3S	1 EA.
2-7	ESWTI TEL DRO	1 EA.
2-8	ESWRE TEL DN 31	1 EA.
2-9	ETRTR 024 075	1 EA.
2-10	ESWMC TEL 1810	1 EA.
2-11	EECTI 024 10M	1 EA.
2-12	ESWCO 024 TEL	1 EA.
2-13	ESWALU TEL DN II	1 EA.
2-14	ESWOL TEL 1308	1 EA.
2-15	ESWOL TEL 1312	1 EA.
2-16	ESWOL TEL 1316	1 EA.
2-17	ESWOL TEL 13X6	1 EA.
2-18	ESWRE 040 8P	1 EA.
2-19	ESWRE 001 8PW	1 EA.
2-20	EECTI 024 PH1	1 EA.
2-21	ESWRE 071 14P	2 EA.
2-22	ESWRB 031 14PD	2 EA.
2-23	EECDE A24 DS3	1 EA.
2-24	ESWRB 030 11PW	1 EA.
2-25	EACTH B10 019	1 EA.
2-26	ECOTS 005	1 EA.
2-27	EECRE 003 024	1 EA.
*		*
QTY. & USE VARIES		*

HY-SECURITY
Gate Operation

TITLE: **ELECTRICAL COMPONENTS**
HVG, HRG 444, 333 & 222
(ALL MODELS, EXCEPT FOR DC MODELS)

DRAWN	DATE	THIRD ANGLE PROJECTION	REV
DB	05/12/00		A
CHECKED	DATE	ERN NUMBER	DATE
-	-	-	-
APPROVED	DATE	DRAWING NUMBER	SHIT OF
-	-	SS40T	1 1



Hy-Security Gate Operators

Phone: 1-800-321-9947 • Fax: (206) 286-0614 • Web: www.hy-security.com • 1200 W Nickerson St • Seattle, WA. 98119

LIMITED WARRANTY (Hydraulically Powered Operators)

Hy-Security Gate Operators warrants all of its manufactured products to the end-user to be free of defects in material and workmanship. The model 111LS is warranted for a period of three years from date of shipment. **All other hydraulic operators are warranted for a period of five years from date of shipment.** Drive wheels for slide gate operators are warranted for a period of two years. Batteries in DC operators and individual replacement parts (that are a design component of the gate operator) are warranted for one year from the date of shipment. Even though included as part of a Hy-Security gate operator, accessories carrying another manufacturers name plate, (unless a design component of the gate operator) shall carry only the warranty of the specific manufacturer.

Any modification made to factory products will void the warranty unless the modifications are approved in writing by the factory, in advance of the change. This exclusion does not apply to normal installation of approved accessories and/or safety devices. This warranty shall not apply to equipment which has been improperly installed, subjected to negligence, accident, damage by circumstances beyond Hy-Security Gate Operators' control, or because of improper operation, maintenance, storage or to other than normal use or service.

Labor to install new parts or remove defective parts, travel time, or standby time is specifically excluded from this warranty. Freight (surface or air) and all other incidental costs are NOT covered by this warranty. There are no obligations or liabilities on the part of Hy-Security Gate Operators for consequential damages arising out of, or in connection with, the use or performance of this product. Hy-Security Gate Operators assumes no responsibility for other indirect damages with respect to loss of property, profit or revenue. This Limited Warranty is valid only in the 50 United States, the District of Columbia and the Commonwealth of Puerto Rico. Implied warranties, including those of merchantability and fitness for a particular purpose or application, are limited to one year from date of shipment.

Defective products that are in warranty should be returned to our factory. At our option, we may elect to repair or replace, free of charge, any such parts. An invoice will be sent at the time replacement parts are shipped, and a credit will be issued only after the parts have been returned undamaged and accepted as defective. No warranty credits will be allowed without written permission from the factory, and the return of the defective part, together with a completed Merchandise Return Form (see our Terms of Sale policy for additional details on the return procedure.) Replacement parts shall carry the remainder of the original limited warranty or 90 days, whichever is longer.

This Limited Warranty gives you specific rights. You may have others, which vary from state to state. This Hy-Security Gate Operators' limited warranty is in lieu of all other warranties expressed or implied. This Limited Warranty supersedes all other warranties.